

Strong coupling of microwaves and magnons in YIG microstructures





Nanostructured
Materials

G. Schmidt

Institut für Physik & Center for materials science

Martin-Luther-Universität Halle Wittenberg

georg.schmidt@physik.uni-halle.de



External collaborators



Nanostructured
Materials

Optics group, MLU Halle

Georg Woltersdorf
Rouven Dreyer

WMI, München

Hans Hübl

CEA and SPINTEC, Grenoble

Olivier Klein
Grégoire de Loubens

Ohio State University

Chris Hammel

Funding by



CRC / TRR 227

Ultrafast Spin Dynamics

DFG Deutsche
Forschungsgemeinschaft

**SFB 762
HARMONY**



Why all this?

The use of coupling phenomena



- There is a technological need to coherently transfer elementary excitations from one type of excitation to another
 - Communication
 - Transfer between microwaves and light
 - Quantum information
 - Qbit readout
 - Transfer and storage of quantum information (single excitation quanta)
- This requires the coupling of different kinds of oscillators
 - Photons (microwave)
 - Photons (light)
 - Phonons (mechanical oscillations)
 - **Magnons that can mediate between those**

Quantum information processing

- Coupling of qubits to magnons successfully demonstrated
- Also promising: coupling of qubits to mechanical oscillators (by electric fields: Chu et al. Science **358**, 199 (2017))
- Why not use magnons and magnetoelastic coupling?



Nanostructured
Materials



(Tabuchi et al. Science **349**, 405 (2015))

Georg Schmidt, Spice Seminar, 2023


Magnonmechanics



Nanostructured
Materials

Magnons and Phonons

- Coupling of magnons and phonons recently demonstrated
- Drawback: YIG resonators are macroscopic spheres (250 μm) not suitable for integration



Zhang et al. *Sci. Adv.* 2016; 2 : e1501286

Georg Schmidt, Spice Seminar, 2023



What is needed?

The effect

- We have one coherent elementary excitation
- We need fast coherent transfer to another excitation (e.g. phonon to magnon)

- Necessary prerequisites
 - Strong coupling
 - Fast coherent energy transfer between two states
 - Large mode overlap
 - Long lived excitations with long decoherence times
 - Longer than energy transfer
 - Long enough for further processing

- So we need strong coupling and narrow linewidth


YIG, linewidth, and Gilbert damping

What is YIG?




- Yttrium iron garnet is a ferrimagnetic garnet with a very complex unit cell (160 atoms)
- It can have a very low Gilbert damping (3×10^{-5})
- Also the resonance linewidth can be very small
- Furthermore it is very rigid and suitable for mechanical resonators



Nanostructured
Materials



Andreas Kreisel PhD thesis



YIG, linewidth, and Gilbert damping

What is the damping α ?

- In the LLG equation the damping appears like a friction
 - More losses at higher precession frequencies

$$\frac{d\vec{M}_{frei}}{dt} = -\gamma \vec{M}_{frei} \times [\vec{H}_{Eff}] + \alpha \vec{M}_{frei} \times \frac{d\vec{M}_{frei}}{dt}$$

- As a result the Gilbert damping α should lead to an increasing line width at higher frequencies



Nanostructured
Materials

YIG, linewidth, and Gilbert damping





Line width or damping?

- Normally the damping is seen as the important parameter to judge the quality of YIG
- The damping α is extracted from the slope of a plot of ΔH_{FMR} versus frequency

$$\mu_0 \Delta H_{FMR} = \mu_0 \Delta H_0 + \frac{\alpha f_{res}}{\gamma}$$

- So in principle a low damping can be achieved even at a large linewidth
- Why?



YIG, linewidth, and Gilbert damping

What linewidth?

- A small detail to look at:
 - Most publications show the linewidth as ΔH_{HWHM} (Half width at half maximum)
 - Some show the linewidth as ΔH_{p-p} measured from the derivative because of lock-in measurements
 - Few show the linewidth as ΔH_{FWHM} (Full width at half maximum)
- The rule is:

$$\Delta H_{FWHM} = 2\Delta H_{HWHM}$$

$$\Delta H_{p-p} = 2/\sqrt{3} \Delta H_{HWHM}$$



Nanostructured
Materials

YIG, linewidth, and Gilbert damping

The inhomogeneous broadening?

- The inhomogeneous broadening can have various reasons. One of them are inhomogeneities that lead to different regions with narrow linewidth and slightly different resonance frequencies
- Is this a problem?



Nanostructured
Materials


YIG, linewidth, and Gilbert damping

The inhomogeneous broadening?

- A large linewidth only means high damping when the linewidth at zero frequency is zero (which it is not)
- The remaining linewidth is called the inhomogeneous or intrinsic broadening: Here some examples



Nanostructured
Materials




GS et al. Phys. Stat.
Sol. B 257, 1900644
(2020)

YIG, linewidth, and Gilbert damping

Different growth methods


- Depending on the growth method, the ratio of linewidth and extracted damping can be quite different



High temperature PLD
 d'Allivy Kelly et al., Applied Physics Letters 103(8), 082408 (2013)



structured
 erials




Room temperature sputtering
 Chang et al., IEEE Magnetics Letters 5, 6700104 (2014)

YIG, linewidth, and Gilbert damping



Different growth methods

- Depending on the growth method, the ratio of linewidth and extracted damping can be quite different



Liquid phase epitaxy

C. Dubs et al. J. Phys. D: Appl. Phys. **50** (2017) 204005



Room temperature PLD

Hauser, GS et al., Scientific Reports

6, 20827 (2016)



Nanostructured Materials

YIG, linewidth, and Gilbert damping

What is important?

- For coupling experiments we need a long lifetime of the magnon states
- The lifetime in principle is given by the damping

$$\tau_0 = \frac{1}{2\pi\alpha f_{\text{res}}}$$

- Does the inhomogeneous broadening hurt?
- If the different regions are coupled, definitely yes!!!
- What if they are uncoupled?



Nanostructured
Materials

YIG, linewidth, and Gilbert damping




What is important?

- In a Gedankenexperiment we use material that has different regions with different resonance frequencies but narrow linewidth




Nanostructured
Materials



YIG, linewidth, and Gilbert damping

What is important?

- We couple this material to a nice superconducting resonator
- For different frequencies or fields different parts of the material are on resonance with long respective magnon lifetimes



- Fine??? No!!!



Nanostructured
Materials


YIG, linewidth, and Gilbert damping

What is important?

- Not only the lifetime counts
- Mode overlap is also important
- Separate resonating regions reduce the mode overlap at a given frequency



Nanostructured
Materials




Strong coupling: A (different) introduction

Two coupled oscillators?

- A very useful example is based on two coupled mechanical oscillators
- The equations of motion are simple:

$$m_A \ddot{x}_A + k_A x_A + \kappa(x_A - x_B) = 0$$

$$m_B \ddot{x}_B + k_B x_B - \kappa(x_A - x_B) = 0$$



Nanostructured
Materials

Strong coupling: A (different) introduction

Two coupled oscillators?

- This equation system has solutions for

$$\omega_{\pm}^2 = \frac{1}{2} \left[\omega_A^2 + \omega_B^2 \pm \sqrt{(\omega_A^2 - \omega_B^2)^2 + 4g\omega_A\omega_B} \right]$$

$$\omega_A = \sqrt{(k_A + \kappa)/m_A} \quad \text{and} \quad \omega_B = \sqrt{(k_B + \kappa)/m_B}$$

$$g = \frac{\sqrt{\kappa/m_A} \sqrt{\kappa/m_B}}{\sqrt{\omega_A \omega_B}}$$

$g = \omega_+ - \omega_-$ is the coupling strength


Note that ω_A and ω_B both contain κ



Strong coupling: A (different) introduction

The anticrossing?

- We consider a system in which one of the oscillators remains at its frequency while the other one changes its spring constant
- Without coupling (left) the two curves cross
- With coupling (right) a gap opens and the curves no longer cross (anticrossing or avoided crossing)
- The size of the gap g shows the strength of the coupling
- What is the nature of these two modes?



Adapted from:
L. Novotny, Am. J.
Phys. **78**, 1199
(2010)



Nanostructured
Materials






Strong coupling: A (different) introduction

Acoustic and optical phonons

- Coupling only



Nanostructured Materials




Strong coupling: A (different) introduction



How do the oscillations look?



- When the two resonance frequencies are different we only have one oscillator on resonance
- The other one follows a forced oscillation
- If the forcing oscillator is at lower frequency, the forced oscillator has only a small phase shift
- If the forcing oscillator is at higher frequency, the forced oscillator has a phase shift $\approx \pi$



Strong coupling: A (different) introduction

What if the two frequencies are degenerate?

- For $k_A = k_B$ and $m_A = m_B$ we observe two Eigenmodes
- Eigenmode 1:
 - Both oscillators in phase (90° - 90°) with the same amplitude
 - The coupling spring sees no deformation $\omega = \sqrt{k/m}$





Nanostructured
Materials



Strong coupling: A (different) introduction

What if the two frequencies are degenerate?

- For $k_A = k_B$ and $m_A = m_B$ we observe two Eigenmodes
 - Eigenmode 2:
 - Both oscillators with phase shift 180° ($90^\circ+90^\circ$) with the same amplitude
 - The coupling spring is deformed in phase with the other spring
- $$\omega = \sqrt{(k + \kappa)/m}$$



Strong coupling: A (different) introduction

Consequence

- The two Eigenmodes are measured on resonance
- These are the only states at these frequencies where no!!! energy is transferred
- In a mixed state (one side only excited) energy transfer happens at the coupling frequency (this is what we need)
- Observation of beating pattern at frequency g



Nanostructured
Materials




Figure 2. Motion of masses and normal modes for $k=0.5$ and $\kappa=4$

From Matthew D. Schwartz, lecture on waves, Harvard University

Strong coupling: A (different) introduction

Damping kicks in

- When we add the damping we get additional terms

$$\gamma_A \dot{x}_A \text{ and } \gamma_B \dot{x}_B$$

- We find that the splitting gets smeared out by the resonance line broadening
- In order to distinguish the lines it is necessary that

$$g > \frac{\gamma_A}{m_A} + \frac{\gamma_B}{m_B}$$

or

$$\frac{g}{\gamma_A/m_A + \gamma_B/m_B} > 1$$

- We consider this a satisfactory condition for strong coupling



Nanostructured
Materials

Strong coupling: A (different) introduction

The cooperativity

- Another important parameter is the so called cooperativity

$$\frac{g^2}{\gamma_A/m_A \times \gamma_B/m_B}$$

- In the strong coupling regime this is always >1
- Attention: Cooperativity >1 is not sufficient for strong coupling
- In the end the first definition (satisfactory condition) was that g is larger than the arithmetic mean of the two linewidths
- The cooperativity compares the coupling strength to the geometric mean of the two linewidths

Now let's get down to business



Nanostructured
Materials



Our target

- Investigate strong coupling of magnons with
 - Light
 - Phonons
 - **Microwaves**



Nanostructured
Materials

A. Osada et al., Phys. Rev. Lett. 116, 223601 (2016)



X. Zhang et al., Sci. Adv. 2016; 2 : e1501286

And do all this with high Q micromagnets

Coupling to cavity photons





What cavity size?

- For high cooperativity, a large overlap of the mode volume is needed
- Hollow cavities work nicely with YIG spheres but are way too big for micromagnets
- What about superconducting resonators?



Nanostructured
Materials

Y. Tabuchi et al. PRL 113, 083603 (2014)





Coupling to cavity photons

What cavity size?

- What about superconducting resonators
- Superconducting $\lambda/4$ resonator still pretty large (λ @cm at 4 GHz)
- Scalable only within limits



Nanostructured
Materials



H. Hübl et al. PRL 111, 127003 (2013)


Coupling to cavity photons

What cavity size?




Nanostructured Materials

- For $\lambda/4$ resonators
 - Demonstration of strong coupling for Py magnets down to 0.1 mm size



Hou et al.,
PRL 123,
107702
(2019)



Li et al.,
PRL 123,
107701
(2019)



Coupling to cavity photons



Nanostructured
Materials

What cavity size?

- Better choice: Superconducting LC resonator (lumped element)
- Magnetic field can be concentrated around an inductive element




Coupling to cavity photons

What cavity size?

- Demonstration of coupling of a Py stripe with LC-resonator
- 40x2x10nm Py element
- High cooperativity but no strong coupling (Py has large linewidth)



Nanostructured
Materials



Hou et al., PRL 123, 107702 (2019)





New resonator design

Modified lumped element resonator

- Central inductance more narrow to localize the magnetic field
 - Py structure of $30\ \mu\text{m} \times 2\ \mu\text{m} \times 50\ \text{nm}$ (1st try)
- Work by Philipp Geyer



Nanostructured Materials



P. Geyer 35



First results

Easy axis

- No FMR at resonator frequency
- Even zero field resonance out of range



Nanostructured
Materials





First results

Hard axis



Nanostructured Materials



- Clear avoided crossing
- However, wrong dispersion direction
- Origin???
- Numbers: $\frac{\Delta\omega_{FMR}}{2\pi} \approx 250 \text{ MHz}$ (conservative estimate), $\frac{\Delta\omega_{Cav}}{2\pi} \approx 1.5 \text{ MHz}$, $\frac{g}{2\pi} \approx 100 \text{ MHz}$
- No strong coupling ($\Delta\omega_{FMR} > g$)
- Cooperativity: $\frac{g^2}{\Delta\omega_{FMR} \Delta\omega_{Cav}} \approx 27$





First results Tilted field

- Second avoided crossing appears
- Second crossing has "correct" dispersion
- Can be explained by micromagnetic simulations






Nanostructured
Materials



Explanation

Unsaturated state

- Close to hard axis the magnet is not saturated
- Resonance field H_{eff} is determined by external field and demagnetizing field
- At low fields H_{demag} and H_{ext} compensate each other
- Saturated state has resonance beyond cavity frequency



Georg Schmidt, Spice Seminar, 2023



Moving towards YIG


Issues

- Nanopatterning of YIG non-trivial
- GGG substrate is detrimental for low temperature measurements
- GGG substrate is also not suitable for superconducting resonators

- Needed
 - Nanopatterned YIG
 - Ideally
 - Either without substrate or
 - On a substrate other than GGG



Nanostructured
Materials



New YIG fabrication process

Allows high Q free standing 3D structures

E-beam lithography and PLD




Subsequent lift-off and annealing

- Damping $\alpha = 2 \times 10^{-4}$

F. Heyroth, GS et al. PR Appl. 12, 054031 (2019)



Nanostructured Materials






Possible applications (first trials)

Mechanical oscillations (Hans Hübl, WMI)

- Cantilever (single side clamped beam) fabricated from bridge
- Excitation by piezoactuation
- Measurement of mechanical vibration by optical interferometry
- Result:
 - Mechanical oscillation at 13.75 MHz
 - Q-factor ~550



Nanostructured
Materials




Getting onto other substrates






Route 1

– Drop casting

- make lots of bridges
- Mask them
- Remove the feet and get them into solution
- Drop cast and use single structure



nanostuctured materials





More fun

Magnon excitation by surface acoustic waves (SAW)

- Fabricate interdigitated transducer on LiNbO_3
- Drop cast YIG nanoslabs on the sample until you find something suitable
- Fix the slab to the surface
- Start shaking and look with TR-MOKE



Nanostructured
Materials




Collaboration with G. Woltersdorf and R. Dreyer, MLU

Route 2




FIB transfer

- Larger structures possible
- Precisely placeable
- New process:

- Structure with multiple feet (centipede) allows for larger YIG areas
- Structure can be detached and transferred using focused ion beam
- Using a few tricks the magnetic properties are preserved




Nanostructured Materials




Magnetometry

- YIG slab transferred to AFM cantilever can be used for cantilever magnetometry



Magnetic resonance force microscopy



- MRFM on transferred YIG slabs



Nanostructured Materials

CEA Grenoble
(G. deLoubens,
I. Ngouagnia
and M. Fontaine)

OSU
(F. Rodriguez,
P.C. Hammel)



Georg Schmidt, Spice Seminar, 2023




YIG on LC resonator

Resonator adapted to sample

- Small area inductance
- YIG transferred by FIB



Nanostructured
Materials





YIG on LC resonator

FIB prepared YIG



Nanostructured
Materials

- Multiple resonances detected along hard and easy axis
- Numbers: $\frac{\Delta\omega_{FMR}}{2\pi} \approx 11 \text{ MHz}$ (estimate), $\frac{\Delta\omega_{Cav}}{2\pi} \approx 1.3 \text{ MHz}$, $\frac{g}{2\pi} \approx 53.8 \text{ MHz}$
- Strong coupling regime ($g > \Delta\omega_{FMR} > \Delta\omega_{Cav}$), Coupling per Spin: $\frac{g_{Spin}}{2\pi} \approx 63 \text{ Hz}$ for $M_{sat} = 140 \text{ kA/m}$
- Cooperativity: $\frac{g^2}{\Delta\omega_{FMR} \Delta\omega_{Cav}} \approx 202$



Conclusion

- LC resonators suitable for downscaling of coupling experiments
- No strong coupling achieved with Py
- New process allows to transfer small YIG structures
- Strong coupling demonstrated
- Cooperativity >200 achieved
- Where are the limits??
(Collaborations to find out are welcome)

